

# **YARIS CLUB UK KNOWLEDGE BASE**



## **OMP Rear Strut Installation**

*N.B This is intended as a guide only, if unsure please seek professional assistance. Yaris Club uk accepts no liability, all work is carried out at the owners own risk. This how-to was constructed while working on an echo, as a result there is the possibility of differences in some of the photos*

Probably one of the easiest mods to do.

What you will need:

14mm socket and wrench, 14mm spanner and the OMP upper rear strut brace.



First, open the rear hatch, squeeze and lift the rear strut top covers.



Then, twist and lift off the caps to reveal the nuts.



Hold the bottom nut with the spanner and undo and remove the top nut with the 14mm socket.



Then your digital camera will stop working.....find a replacement :lol:

Fit the brace on top of the remaining nut either side, making sure it is level.



Replace the nuts inside the brace, then then tighten

with the socket.



Keep the strut caps and covers somewhere safe.

Stand back, light your pipe, and admire your handywork :D

